

1 Connect your player to your computer's USB port



For more info, go to:
www.sandisk.com/ClipJam/USB

2 Charge your Clip Jam Player and transfer music



For more info, go to:
www.sandisk.com/ClipJam/Transfer

Clip Jam™ MP3 Player

At-A-Glance



STOP!
IMPORTANT INFORMATION
YOU MUST READ THIS BEFORE
USING THE MP3 PLAYER

Safety Instructions

Your MP3 player is equipped with a variety of features. To help you maximize your listening pleasure, SanDisk would like to advise you that it is important to use the headphones with your MP3 player at a safe hearing level. For more safety information, please go to www.sandisk.com/dipjam/Safety

SanDisk One-Year Warranty

The SanDisk Clip Jam MP3 player is covered by this warranty for one (1) year, subject to the applicable warranty terms and conditions, as defined at www.sandisk.com/wug.

Disposal Instructions

Do not dispose of this device with unsorted waste. Improper disposal may be harmful to the environment and human health. Please refer to your local waste authority for information on return and collection systems in your area.

Online User Manual and End-User License Agreement

Please go to www.sandisk.com/support to retrieve your online User Manual and End User License Agreement.

FCC Compliance

This device complies with part 15 of the FCC Rules.
www.sandisk.com/dipjam/FCC

For more info, go to:
www.sandisk.com/ClipJam

SanDisk is a trademark of SanDisk Corporation, registered in the United States and other countries. Clip Jam is a trademark of SanDisk Corporation. The microSDHC mark and logo are trademarks of SD-3C, LLC.

© 2015 SanDisk Corporation. All rights reserved. Made in China.

80-36-03731

SanDisk

QUICK
START
GUIDE

For more info, go to:
sandisk.com/ClipJam

